


Drone Tuning Too High

If your drone is tuning too high, remove the nose cone from the reed by twisting it off. **Take care when doing this so as not to damage the reed body.** Using the Allen key, turn the setscrew in a clockwise direction, thereby lengthening the column of air and lowering the pitch of the reed.

Drone Tuning Too Low

Remove the nose cone as instructed above and turn the setscrew in an anti-clockwise direction, shortening the column of air and raising the pitch of the reed.

We believe that **Canning Drone Reeds** are the best reeds ever to hit the market. In the unlikely event that you encounter any problems, please visit us online at www.canningreeds.com for further help & advice.



CANNING
REED MAKERS



**Bagpipe
Drone Reeds**

INSTRUCTIONS

www.canningreeds.com
info@canningreeds.com